



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Suzuki 1200 Bandit

### 465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. The shouldered sleeves should already be installed in the shock eye. If not, insert the sleeves with O-rings in the shock eye.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing forward. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: The installed spring length must never be set shorter than 5.25" or shock damage may occur.

Note: 1997 1200 Bandit with Anti-lock brakes (SAV) must order Suzuki part #09103-10101 (bolt) and #08319-31107 (nut) for the lower mount. These items are not included with the shock, but can be ordered at any Suzuki dealer.

[www.progressivesuspension.com](http://www.progressivesuspension.com)

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Suzuki 1200 Bandit

### 465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. The shouldered sleeves should already be installed in the shock eye. If not, insert the sleeves with O-rings in the shock eye.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing forward. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: The installed spring length must never be set shorter than 5.25" or shock damage may occur.

Note: 1997 1200 Bandit with Anti-lock brakes (SAV) must order Suzuki part #09103-10101 (bolt) and #08319-31107 (nut) for the lower mount. These items are not included with the shock, but can be ordered at any Suzuki dealer.

[www.progressivesuspension.com](http://www.progressivesuspension.com)

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Suzuki 1200 Bandit

### 465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. The shouldered sleeves should already be installed in the shock eye. If not, insert the sleeves with O-rings in the shock eye.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing forward. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: The installed spring length must never be set shorter than 5.25" or shock damage may occur.

Note: 1997 1200 Bandit with Anti-lock brakes (SAV) must order Suzuki part #09103-10101 (bolt) and #08319-31107 (nut) for the lower mount. These items are not included with the shock, but can be ordered at any Suzuki dealer.

[www.progressivesuspension.com](http://www.progressivesuspension.com)

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Suzuki 1200 Bandit

### 465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. The shouldered sleeves should already be installed in the shock eye. If not, insert the sleeves with O-rings in the shock eye.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing forward. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: The installed spring length must never be set shorter than 5.25" or shock damage may occur.

Note: 1997 1200 Bandit with Anti-lock brakes (SAV) must order Suzuki part #09103-10101 (bolt) and #08319-31107 (nut) for the lower mount. These items are not included with the shock, but can be ordered at any Suzuki dealer.

[www.progressivesuspension.com](http://www.progressivesuspension.com)

Copyright © 2009 by Progressive Suspension. All Rights Reserved.