



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

**BMW K100RS/K1100RS/LT/RSA/LTA  
Paralever Models  
465 Series Single Shock Supplement**

***Please read these instructions completely before starting!***

1. Shouldered sleeves should already be installed in the shock eyes. If not, insert the sleeves with O-Rings in the shock eyes.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted shaft end up, with the rebound adjustment and the nitrogen pressure valve is facing the rear of the motorcycle. Tighten the shock bolts to the proper torque specifications (refer to your manual).

**Caution:** *The installed spring length must never be set shorter than 7.00" or shock damage may occur.*

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

**BMW K100RS/K1100RS/LT/RSA/LTA  
Paralever Models  
465 Series Single Shock Supplement**

***Please read these instructions completely before starting!***

1. Shouldered sleeves should already be installed in the shock eyes. If not, insert the sleeves with O-Rings in the shock eyes.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted shaft end up, with the rebound adjustment and the nitrogen pressure valve is facing the rear of the motorcycle. Tighten the shock bolts to the proper torque specifications (refer to your manual).

**Caution:** *The installed spring length must never be set shorter than 7.00" or shock damage may occur.*

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

**BMW K100RS/K1100RS/LT/RSA/LTA  
Paralever Models  
465 Series Single Shock Supplement**

***Please read these instructions completely before starting!***

1. Shouldered sleeves should already be installed in the shock eyes. If not, insert the sleeves with O-Rings in the shock eyes.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted shaft end up, with the rebound adjustment and the nitrogen pressure valve is facing the rear of the motorcycle. Tighten the shock bolts to the proper torque specifications (refer to your manual).

**Caution:** *The installed spring length must never be set shorter than 7.00" or shock damage may occur.*

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

**BMW K100RS/K1100RS/LT/RSA/LTA  
Paralever Models  
465 Series Single Shock Supplement**

***Please read these instructions completely before starting!***

1. Shouldered sleeves should already be installed in the shock eyes. If not, insert the sleeves with O-Rings in the shock eyes.
2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted shaft end up, with the rebound adjustment and the nitrogen pressure valve is facing the rear of the motorcycle. Tighten the shock bolts to the proper torque specifications (refer to your manual).

**Caution:** *The installed spring length must never be set shorter than 7.00" or shock damage may occur.*

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.