



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Kawasaki Concours

465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Shouldered sleeves with O-rings should already be installed in the shock eye. If not, insert sleeves with O-rings in shock eye.

2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure shock is mounted with the rebound adjustment at the bottom and facing the right side of the motorcycle and nitrogen pressure valve is facing the forward. Tighten shock bolts to the proper torque specifications (refer to authorized shop manual).

Caution: The installed spring length must never be set shorter than 5.75" or shock damage may occur.

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Kawasaki Concours

465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Shouldered sleeves with O-rings should already be installed in the shock eye. If not, insert sleeves with O-rings in shock eye.

2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure shock is mounted with the rebound adjustment at the bottom and facing the right side of the motorcycle and nitrogen pressure valve is facing the forward. Tighten shock bolts to the proper torque specifications (refer to authorized shop manual).

Caution: The installed spring length must never be set shorter than 5.75" or shock damage may occur.

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Kawasaki Concours

465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Shouldered sleeves with O-rings should already be installed in the shock eye. If not, insert sleeves with O-rings in shock eye.

2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure shock is mounted with the rebound adjustment at the bottom and facing the right side of the motorcycle and nitrogen pressure valve is facing the forward. Tighten shock bolts to the proper torque specifications (refer to authorized shop manual).

Caution: The installed spring length must never be set shorter than 5.75" or shock damage may occur.

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Kawasaki Concours

465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Shouldered sleeves with O-rings should already be installed in the shock eye. If not, insert sleeves with O-rings in shock eye.

2. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure shock is mounted with the rebound adjustment at the bottom and facing the right side of the motorcycle and nitrogen pressure valve is facing the forward. Tighten shock bolts to the proper torque specifications (refer to authorized shop manual).

Caution: The installed spring length must never be set shorter than 5.75" or shock damage may occur.

www.progressivesuspension.com

Copyright © 2009 by Progressive Suspension. All Rights Reserved.