



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha Road Liner/Stratoliner
465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the rear, facing down and the nitrogen pressure valve is facing up.
2. Tighten the shock bolts to the proper torque specifications (*refer to your manual*).

Caution: The installed spring length must never be set shorter than 5.50" for 465-1161 or 4.80" for 465-1160 or shock damage may occur.



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha Road Liner/Stratoliner
465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the rear, facing down and the nitrogen pressure valve is facing up.
2. Tighten the shock bolts to the proper torque specifications (*refer to your manual*).

Caution: The installed spring length must never be set shorter than 5.50" for 465-1161 or 4.80" for 465-1160 or shock damage may occur.



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha Road Liner/Stratoliner
465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the rear, facing down and the nitrogen pressure valve is facing up.
2. Tighten the shock bolts to the proper torque specifications (*refer to your manual*).

Caution: The installed spring length must never be set shorter than 5.50" for 465-1161 or 4.80" for 465-1160 or shock damage may occur.



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha Road Liner/Stratoliner
465 Series Single Shock Supplement

Please read these instructions completely before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the rear, facing down and the nitrogen pressure valve is facing up.
2. Tighten the shock bolts to the proper torque specifications (*refer to your manual*).

Caution: The installed spring length must never be set shorter than 5.50" for 465-1161 or 4.80" for 465-1160 or shock damage may occur.