



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha XV19 Raider 465 Series Single Shock Supplement

Please read these instructions completely before starting!

Mount the shock, referencing your authorized shop manual, noting the following important details;

Make sure the shock is mounted with the rebound adjustment toward the rear and facing the right side of the motorcycle and the nitrogen pressure valve is facing up. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: *The installed spring length must never be set shorter than 5.70" for 465-1168 and 5.37" for 465-1169 or shock damage may occur.*

<http://www.progressivesuspension.com>



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha XV19 Raider 465 Series Single Shock Supplement

Please read these instructions completely before starting!

Mount the shock, referencing your authorized shop manual, noting the following important details;

Make sure the shock is mounted with the rebound adjustment toward the rear and facing the right side of the motorcycle and the nitrogen pressure valve is facing up. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: *The installed spring length must never be set shorter than 5.70" for 465-1168 and 5.37" for 465-1169 or shock damage may occur.*

<http://www.progressivesuspension.com>