



Supplement to Fork Spring Instructions For BMW R65, Part #11-1125

1. Spacer must be used to provide proper setting for the fork spring, over the damper rod.
2. To install, coat the spacer and the bottom of the fork spring (opposite of the close wound coil end) with grease. Press the spacer onto the bottom of the for spring making sure the spacer and spring stick together. Carefully slide the fork spring (with attached spacer) into the for tube.




Supplement to Fork Spring Instructions For BMW R65, Part #11-1125

1. Spacer must be used to provide proper setting for the fork spring, over the damper rod.
2. To install, coat the spacer and the bottom of the fork spring (opposite of the close wound coil end) with grease. Press the spacer onto the bottom of the for spring making sure the spacer and spring stick together. Carefully slide the fork spring (with attached spacer) into the for tube.



Supplement to Fork Spring Instructions For BMW R65, Part #11-1125

1. Spacer must be used to provide proper setting for the fork spring, over the damper rod.
2. To install, coat the spacer and the bottom of the fork spring (opposite of the close wound coil end) with grease. Press the spacer onto the bottom of the for spring making sure the spacer and spring stick together. Carefully slide the fork spring (with attached spacer) into the for tube.



Supplement to Fork Spring Instructions For BMW R65, Part #11-1125

1. Spacer must be used to provide proper setting for the fork spring, over the damper rod.
2. To install, coat the spacer and the bottom of the fork spring (opposite of the close wound coil end) with grease. Press the spacer onto the bottom of the for spring making sure the spacer and spring stick together. Carefully slide the fork spring (with attached spacer) into the for tube.

